

Fire Extinguisher Cabinet Instructions

#1 ROUGH OPENINGS - HEIGHT & WIDTH

A. Non-rated cabinets installed in metal stud wall system: rough openings using metal studs should be 1/4" larger than the outside dimension of the cabinet tub.

B. Non-rated cabinets installed in wood stud wall systems: rough openings using double wood stud construction on all four sides of the cabinet tub unit should be 1/4" larger than the outside dimension of tub unit.

Caution: Should a load-bearing stud be cut to install the cabinet, ensure that a load header be reinstalled.

C. Rough openings must not be less than manufacturer's recommended dimensions.

#2 DETERMINE CENTER LOCATION OF STUD

#3 DRILLING HOLES

Drill 3/16" holes every 10" through double-sided wall construction and ends of cabinet, making sure to stay in center of the studs.

#4 CABINET PLACEMENT

Cabinet in framed opening must be centered and leveled top to bottom and side to side.